


EFE Rail Adams T3 Additional body removal instructions

Loco body removal should not usually be required; these additional instructions should be read in conjunction with the main user instructions.



#1 This shows the model pre-removal of the chassis and highlights the inside motion. The instructions state that the "Cylinder Drain Cock operating arm" needs removing before the body is separated from the chassis. In addition, the inside motion detail (as highlighted) also needs removing.



#2 The inside motion detail is held by two pins which locate into the running plate, to remove it, simply take a pair of tweezers and ease the part away from the running plate. The photo shows both parts having been removed, allowing the chassis and motor to come away from the frames.